

NOTICE DE MONTAGE

ECOPE DE RADIATEUR ERMAX ADAPTABLES SUR YAMAHA MT10 2016 → ∞

Durée de montage estimée : 25mn

**Le montage des écopes de radiateur Ermax implique
la suppression des clignotants d'origine. Pensez à vous munir de blinkers de remplacement
(trou percé au diamètre 8)**

Kit de fixation

- 2 entretoises plastique 10x20x5
- 2 entretoises plastique 6x20x10



Ecope supérieure

Montage

- Démonter les écopes supérieures.
- Débrancher les clignotants.
- Retirer les écopes de radiateur d'origine.
- A droite, installer les entretoises plastiques 10x20x5 sur les inserts du réservoir de liquide de refroidissement, puis installer l'écope de radiateur Ermax à l'aide des vis d'origines.
- A gauche, positionner l'écope de radiateur Ermax à l'aide des vis d'origine et des entretoises 6x20x10.
- Remettre les écopes supérieures.

« ATTENTION »

* Les pièces peintes et vernies ne sont pas garanties contre les lavages vapeur « haute pression » ou les produits nettoyants agressifs qui peuvent les endommager et décoller le vernis. Nous conseillons d'ailleurs, d'après les données techniques de nos fournisseurs en peinture, d'**attendre un mois** afin d'obtenir une polymérisation complète du vernis.

* Tout accessoire monté ne sera plus considéré comme neuf et ne sera **ni repris ni échangé**.

* Les accessoires Ermax sont conçus pour des **montes d'origine**. Ils ne seront pas garantis s'ils sont utilisés dans d'autres conditions.

* En raison des tolérances de fabrication des véhicules, indépendantes de notre volonté, certains produits Ermax peuvent nécessiter des ajustements lors de la fixation.

* Les marques de fabricant de motos citées sont indiquées exclusivement comme référence nécessaire à la destination des accessoires Ermax.

* Attention aux serrages excessifs qui pourraient abîmer ou casser nos accessoires en plastique et les vis en aluminium.

FITTING INSTRUCTIONS

ERMAX RADIATOR SCOOPS ADAPTABLE ON YAMAHA MT10 2016 → ∞

Estimated mounting time : 25mn

**Original indicators cannot be used any longer with Ermax scoops.
You must provide spare blinkers (hole drilled at diameter 8).**

Fitting kit

- 2 plastic washers 10x20x5
- 2 plastic washers 6x20x10



Top scoop

Fitting instructions

- Remove the top scoops.
- Disconnect the indicators.
- Remove the original radiator scoops.
- On the right side, place the plastic washers 10x20x5 on the inserts of the coolant tank, then install the Ermax scoop by using the original screws.
- On the left side, install the Ermax scoops thanks to the original screws and the washers 6x20x10.
- Replace the top scoops.

« CAUTION »

* Painted and varnished parts are not guaranteed against high pressure steam washes or aggressive cleaning products which can damage them and unstuck the varnish. We advise moreover, according to the technical data of our painting suppliers, **to wait one month** to obtain a complete polymerization of varnish.

* Accessories gone up on the motorbike will not be any more considered as new and will be **neither retaken nor exchanged**.

* Ermax accessories are foreseen for **original equipments**. They will not be guaranteed if they are used in others conditions.

* Due to vehicles made tolerances, beyond our control, some Ermax products might need adjustings to fit.

* The mentioned label of motorbikes's manufacturers are indicated exclusively as a reference to Ermax accessories.

* Care to excessive clampings which may damage or break our plastic accessories and aluminium screws.